



In open position to re-attach
the headsail luff tape



In closed position to guide
the sail perfectly



New Opening Luff Rope Prefeeder for Racing Foils and Furling Systems

Performance

Before re-hoisting the bowman doesn't need to remove the headsail from the luff groove, he just has to open the prefeeder and close it around the luff tape. No need to remove the headsail anymore!

Ease of use

To open simply push the spring with your thumb, the jaws will open automatically. To close, squeeze the jaws together between thumb and fingers, until the spring reengages.

Easy to instal

The prefeeder can be easily installed below any headsail foil or headsail reefing configuration. In the closed position, it ensures a smooth and easy sail hoist.

- > Single handed operation by pushing on the spring.
- > Easy to install with a lashing or fixed to the forestay.
- > Stainless steel product benefiting from the Wichard know-how to offer the highest reliability.
- > **Product number: 7485**